

Please read these instructions carefully before installing and using the product!



## 1. PRODUCT INTRODUCTION

**1.1** USB-C charging cabinet is designed to charge and store Chromebooks, laptops, tablets, iPad devices etc. It is predominantly used in schools, airports, railway stations, hotels, bars, residential establishments and so on, where a great number of electrical devices need to be charged and stored simultaneously.

**1.2** IT supports QC2.0, QC3.0, QC4/4+, PD2.0, PD3.0, PPS, FCP, BC1.2.

**1.3** This product has over current protection, over voltage protection and short circuit protection etc.

**1.4** Cooling fan and vents on the housing together, significantly reduce the temperature of devices during charging.



**1.5** LED indicators show charging status of devices.

**1.6** EVA mat at bottom to protect the devices from slipping and scratching.

## 2. SPECIFICATION

Model	D0212
Input	100-240V ~ 50/60Hz 8A
Standard	EN62368.1, IEC62368.1
Protection	Over current protection, Over voltage protection , Short circuit protection
Output	5V/3A,9V/3A,12V/3A,15V/3A,20V/2.25A, 45W each port,
Bay Dimensions(mm )	32 (W) 245 (H) 380 (D) mm
Product Dimension(mm )	500(W) 385 (H) 395(D)mm
Net Weight(kg)	16kg
Working Environment	Working temperature: 0°C - 40°C; Storage: -20°C - 50°C Working humidity: 30% - 80% without condensation

## 3. DIAGRAM



## 4. INSTALLATION

- 4.1 Please keep the product perpendicular to the ground;
- 4.2 Do not block the ventilation openings so proper air flow

## 5. HOW TO USE

- 5.1 Plug in the power cord into the wall socket.
- 5.2 Unlock the door.
- 5.3 Place devices into the slot of the product.
- 5.4 Connect devices to the product with USB-C cable.
- 5.5 Turn on switch, then the product will start to charge devices.

## 6. SAFETY WARNING

- 6.1 Wall socket must have a protective ground wire;
- 6.2 Please don't frequently switch on/off the product;
- 6.3 Please don't disassemble, modify the product, please don't use it in high temperature and humid environment or in water;
- 6.4 Maintenance and repairs should always be performed by qualified professional technicians.
- 6.5 Unplug this product when unused;
- 6.6 Make sure there is no liquid, flammable, explosive or debris around.

## 7. ORDINARY MALFUNCTION AND REMOVAL

The product can't charge devices:

### 7.1 LEDs don't light up

- a. Check if power cord is connected properly.
- b. Check if the switch is on.
- c. Use another power cord.

### 7.2 LEDs light up :

- a. Check if USB cable is connected properly.
- b. Use another USB-C cable.

If above methods cannot correct the fault, please contact the dealer.